

# SENCON



Instructions  
Consignes  
Anleitung  
Instructies  
Instrucciones  
Instruções  
Istruzioni  
Instrukcje  
Návod  
Talimatlar

инструкции  
οδηγίες  
הוראות  
تعليمات  
নির্দেশ  
ขอแนะนำ  
 hướng dẫn  
说明  
훈령  
手順







**NORTH, CENTRAL & SOUTH AMERICA**  
Telephone: +1 708 496 3100 Fax: +1 708 496 3105  
Email: sales@sencon.com

**EUROPE • MIDDLE EAST • ASIA**  
Telephone: +44 1905 827800 Fax: +44 1905 795876  
Email: sales@sencon.co.uk




**FRANCE - SPAIN**  
France tél: +33 1 76 64 12 87  
Espagne tél: +34 93 754 95 26  
Deutschland, tel: +49 30 87333-3807  
Fax: +44 1905 456393  
Email: info@sencon.eu

**www.sencon.com**


097-10400-02




## QA4400



# SI9507-SI9507+



# SI9550-SI9650



4

SI9500

**CALIBRATE**

PASS → CALIBRATE → CP → ENTER → 0.00 → END → END

**LACQUER NUMBER**

---

SI9600

Measurement setup

1 → 0 → ← → ← → ←